



1



2



3



4



YEALINK DESKPHONE CALL HOLD AND PICK UP

- The held call is indicated by a flashing green line key and "Hold" indicators on the phone display
- The call will remain on hold indefinitely
- The phone will play a reminder tone after 90 seconds



5



YEALINK DESKPHONE CALL HOLD AND PICK UP

- To pick up the held call, press the:
 - Hold button
 - [Resume] softkey
 - Flashing green line key
- The caller may only be picked up from your phone



6

POPP
www.popp.com

YEALINK DESKPHONE
CALL HOLD AND PICK UP

For more training videos, visit
www.popp.com/support

7

POPP
www.popp.com

YEALINK DESKPHONE

CALL PARK AND PICK UP PARKED CALL

NOTE: THIS VIDEO FEATURES A T54W. PROCEDURE MAY VARY ON SOME MODELS.

8



YEALINK DESKPHONE CALL PARK AND PICK UP PARKED CALL

- Press one of the available [Call Park] keys indicated by a green light



9



YEALINK DESKPHONE CALL PARK AND PICK UP PARKED CALL

- The key will flash red and will alert on all phones in your system
- Tell the recipient that they have a call on park



10

POPP
www.popp.com

YEALINK DESKPHONE CALL PARK AND PICK UP PARKED CALL

- To pick up a parked call, press the flashing Park key, then lift the handset

The image shows a close-up of the Yealink deskphone's color LCD screen. The screen displays the following information:

- Top status bar: 7632316442, 8:36 AM Mon, May 02
- Call ID: 7632316442
- Line 2 - 3941
- Paging icon and text
- Park 100** (highlighted with a red box)
- Park 100 icon and text
- Bottom menu: History, Directory, DND, Menu

11

POPP
www.popp.com

YEALINK DESKPHONE CALL PARK AND PICK UP PARKED CALL

For more training videos, visit
www.popp.com/support

The image shows the full Yealink deskphone unit. The handset is on the left. The screen displays:

- Top status bar: 7632316442, 12:16 PM Fri, Apr 08
- Call ID: 7632316442
- Park 100
- EME - Ext 3941
- Bottom menu: History, Directory, DND, Menu

12